

700 R4 Lock up kit Installation Instructions
Provided by Larry's Electric
Version 2
(compact vacuum switch)

Remove pan and filter from transmission. Retain all parts. Remove existing parts and wires. Retain TCC solenoid.

1. Install brake light switch (set to engaged position—switch pushed in—when brake pedal is released).
2. Mount vacuum switch and run 1/8th inch vacuum hose to intake manifold vacuum.
3. Run power to brake switch (fused supply). Connect the two blue wires to the front terminals
4. On the end of the black wire crimp terminal supplied and solder. Install into plastic connector.
5. Plug white four prong plug into existing transmission plug.
6. From existing 4 prong trans body plug remove all wires except the wire in slot "A". This wire must go to one side of the TCC solenoid. The other wire goes to the fourth gear pressure switch (use terminal and plastic body supplied in kit)
7. Attach connector to 4th gear pressure switch.
8. Tie up all wires to make things neat.
9. Reinstall filter (new if desired) and pan and fill with fill with proper level of fluid.

Any questions or comments call 618-282-2852 or visit us on the web @ www.larryselectricsite.com

